

User's Manual

TX1001 Digital Thermometer

Store this manual in an easily accessible place for quick reference.

Printed in Japan

YOKOGAWA
Yokogawa Test & Measurement Corporation

All Rights Reserved. Copyright ©
2015 Yokogawa Test & Measurement Corporation

IM TX10-01E
11th Edition:
April 2024 (YMI)

Introduction

Thank you for purchasing the Digital Thermometer TX1001. This User's manual contains useful information regarding the instrument's functions and operating procedures, as well as precautions that should be observed during use. Before using this product, thoroughly read this manual to understand how to use it properly. The following manuals, including this one, are provided as manuals for the TX1001. Please read all manuals.

MODEL: TX1001		
IM TX10-01E:	Safety precautions, Specifications, etc. (this manual)	
IM TX10-01-02EN:	[Operation Manual]	
IM 00C01C01-01Z1:	Safety manual (European languages)	
IM CROHS-TX:	Document for China	
IM TX10-93Z2:	Document for Korea	

For products whose suffix code contains “Z,” an exclusive manual may be included. Please read it along with the standard manual.

Contact information of Yokogawa offices worldwide is provided on the following sheet.

PIM 113-01Z2:	Inquiries	List of worldwide contacts
---------------	-----------	----------------------------

The contents of this manual are subject to change without prior notice as a result of improvements to the product's performance and functionality. Refer to our website to view our latest manuals.

1. Safety Precautions

This product is designed to be used by a person with specialized knowledge. The general safety precautions described herein must be observed during all phases of operation. If the instrument is used in a manner not specified in this manual, the protection provided by the instrument may be impaired. This manual is part of the product and contains important information. Store this manual in a safe place close to the instrument so that you can refer to it immediately. Keep this manual until you dispose of the instrument. YOKOGAWA assumes no liability for the customer's failure to comply with these requirements. The following safety symbols are used on the instrument and in the manual:

	Danger! Handle with Care. This symbol indicates that the operator must refer to an explanation in the User's Manual or Service Manual in order to avoid risk of injury or loss of life of personnel or damage to the instrument.	
	WARNING	Indicates a hazard that may result in the loss of life or serious injury of the user unless the described instruction is abided by.
	[French] Avertissement	Indique un danger risquant d'entraîner la mort ou de graves blessures si les instructions présentées ne sont pas respectées.
	CAUTION	Indicates a hazard that may result in an injury to the user and/or physical damage to the product or other equipment unless the described instruction is abided by.
	[French] Attention	Indique un danger risquant d'entraîner une blessure et/ou un dégât physique du produit ou d'un autre équipement si les instructions présentées ne sont pas respectées.
	Note	Indicates information that is essential for handling the instrument or should be noted in order to familiarize yourself with the instrument's operating procedures and/or functions.
TIP	Indicates additional information to complement the present topic.	

■ Be sure to comply with the following safety precautions. Failure to do so may result in loss of life or injury to personnel from such hazards as electrical shock, or damage to the instrument.

 WARNING

- This instrument is a thermometer (thermocouple used). Do not use this instrument for other purpose.
- Do not use the instrument if there is a problem with its physical appearance.
- Do not use the instrument to measure where there is the risk of electrical shock.
- When handling a needle-type probe, be careful not to point the tip in the direction of any person as doing so may result in an injury.
- After measuring anything with a high temperature, do not touch the metal part of the measuring probe as this may result in a burn.
- Do not open the case except when replacing batteries.
Only qualified YOKOGAWA personnel may remove the covers and disassemble or alter the instrument. Do not attempt to repair the instrument yourself, as doing so is extremely dangerous. When the instrument needs an internal inspection or calibration, contact Yokogawa or the dealer from whom you purchased the instrument.

 CAUTION

- When the instrument is stored for a long period of time, be sure to remove the batteries. Not doing so may result in a failure or malfunctioning of the instrument due to a leakage in battery liquid.
- Do not use deteriorated or damaged probes, as doing so will effect the precision of measurements.
- Before you detach the probe from the instrument, always remove the probe from the object being measured.
- When using a needle-type probe, do not insert the metal part of the measuring probe more than half its the length into the object to be measured, as doing so may result in a burn or damage to the probe due to the handle of the probe heating up.
- Keep the handle of the probe and the cable that connects the probe to the instrument within a temperature range of -20°C to 50°C, as they are less resistant to heat than the metal part of the measuring probe.

 CAUTION

The use of this instrument is limited to residential, commercial, and light-industrial environments. This instrument may not be able to measure accurately if it is near other equipment generating strong electromagnetic interference or a strong magnetic field caused by large current.

■ Veuillez respecter les consignes de sécurité suivantes. Le non-respect de ces consignes risquerait d'entraîner la mort ou des blessures dues à un choc électrique ou d'endommager l'instrument.

 Avertissement

- Cet instrument est un thermomètre (thermocouple utilisé).
Ne pas utiliser cet instrument à d'autres fins.
- Ne pas utiliser cet instrument t si son aspect physique pose problème.
- Ne pas utiliser cet instrument pour évaluer le risque de choc électrique.
- Lors de la manipulation d'une sonde de type aiguille, faire attention de ne pas la pointer en direction d'une personne, car cela risquerait de la blesser.
- Après avoir mesurer un élément à haute température, ne pas toucher la partie métallique de la sonde de mesure car cela risquerait d'entraîner une brûlure.
- N'ouvrez pas le boîtier sauf lors du remplacement des piles.
Seul le personnel YOKOGAWA qualifié est habilité à retirer le capot et à démonter ou modifier l'instrument. Ne pas tenter de réparer l'instrument soi-même, car cela est extrêmement dangereux. Si l'instrument nécessite une inspection ou un étalonnage interne, contactez YOKOGAWA ou le revendeur auprès duquel vous avez acheté l'instrument

 Attention

- Si l'instrument est stocké pendant une longue période, s'assurer que les piles ont été retirées. Cela risquerait sinon d'entraîner une défaillance ou un dysfonctionnement de l'instrument dû(e) à une fuite du liquide des piles.
- Ne pas utiliser de sondes détériorées ou endommagées, car cela risquerait d'avoir un impact sur la précision des mesures.
- Avant de débrancher la sonde de l'instrument, toujours la retirer de l'objet en cours de mesure.
- Lors de l'utilisation d'une sonde de type aiguille, ne pas insérer la partie métallique de la sonde de mesure de plus de la moitié de sa longueur dans l'objet à mesurer, car cela risquerait de brûler ou d'endommager la sonde suite à une surchauffe de la poignée de la sonde.
- Maintenir la poignée de la sonde et son câble de raccordement à l'instrument à une température comprise entre -20 °C et 50 °C, car ces éléments sont moins résistants à la chaleur que la partie métallique de la sonde de mesure.

 Attention

L'utilisation de cet instrument est limitée aux environnements résidentiels, commerciaux et industriels légers. Cet instrument peut ne pas être en mesure d'effectuer des mesures de précision s'il se trouve à proximité d'autres équipements générant de fortes interférences électromagnétiques ou d'un champ magnétique puissant provoqué par un courant important.

Measurement category

 WARNING

- The instrument is designed for measurement category O (Other).
- Do not use the instrument for measurements in locations falling that fall under measurement categories II, III, and IV.
Additionally, do not connect to above locations (categories) the temperature probe (accessory).
- Do not use the instrument to measure voltage or current.

 Avertissement

- L'instrument est conçu pour la catégorie de mesures O (Autres).
- Ne pas utiliser cet instrument de mesure dans des emplacements de catégorie de mesure II, III et IV.
De plus, ne pas connecter la sonde de température (accessoire) aux emplacements (catégories) mentionnés ci-dessus.
- Ne pas utiliser cet instrument pour mesurer la tension ou le courant.

Measurement Category	Description	Remarks
O (None, Other)	Other circuits that are not directly connect to MEAINS.	Circuits not connected to a mains power source.
CAT II	For measurement preformed on circuits directly connected to the low-voltage installation.	Appliances, portable equipment, etc.
CAT III	For measurement preformed in the building installation.	Distribution board, circuit breaker, etc.
CAT IV	For measurement preformed at the source of the low-voltage installation.	Overhead wire, cable systems, etc.

The estimated transient overvoltage that may appear at the instrument signal input is 350 V.

2. Cleaning and After-Sales Service

■ Cleaning

- If the instrument becomes dirty, wipe the instrument with a cloth that has been dampened with water and well wrung.
- If the instrument is very dirty, use a cloth that has been dampened with a diluted neutral detergent. Do not use other detergents, solvents, or chemicals. Doing so may cause a failure of the instrument.
- Avoid any water or other liquids from splashing onto the connector, as this may cause a failure of the instrument.

■ After-Sales Service

Please direct question about this product to the contact listed on the “Inquiries” or to your nearest Yokogawa dealer.

3. Handling Precautions

⚠ CAUTION

- Each probe has its own maximum and minimum operating temperatures, so ensure that its temperature does not fall outside the specified range.
- As the probe is susceptible to corrosion, do not use the instrument for the measurement of gas or liquid, and refrain from measuring semi-solid particles and semi-viscous substances. After measurement, wipe the probe with a dry cloth.
- Do not apply a strong force to the upper and lower parts of the probe as doing so may result in the bending of the probe connector.
- When using the instrument be careful not to bend, drop, or strike the measurement probe.
- When measuring surface temperature using a surface-type probe, position the probe perpendicular to the surface of the object. Also note that the application of oil to the probe for the means of providing better contact can improve measurement accuracy.
- When measuring non-metallic surface temperature, make sure the measurement time is long enough to compensate for poor thermal conductivity.
- To ensure stable measurement, the instrument should not be subjected to a sudden temperature change.
- This instrument, with the exception of the connector section, is water-resistant but not waterproof. Therefore the instrument should not be immersed in water.
If it is mistakenly immersed in water, remove it immediately and check to ensure that no water has penetrated inside the case. Although this instrument is designed so that any water penetrating into the connector does not permeate into the circuit inside the case, try to prevent any water entering the connector. If water does enter the connector, the burnout display may be unavailable.

⚠ Attention

- Chaque sonde possède ses propres températures de fonctionnement maximales et minimales. Il faut donc s'assurer que sa température ne tombe pas sous la plage spécifiée.
- La sonde étant sensible à la corrosion, ne pas utiliser l'instrument pour la mesure de gaz ou de liquide et éviter de mesurer des particules semi-solides et des substances semi-visqueuses. Après la mesure, essuyer la sonde avec un chiffon sec.
- Ne pas exercer une force puissance sur les parties supérieures et inférieures de la sonde, car cela risquerait de faire plier le connecteur de sonde.
- Lors de l'utilisation de l'instrument, faire en sorte de ne pas plier, faire tomber ou cogner la sonde de mesure.
- Lors de la mesure de la température de surface à l'aide d'une sonde de type sonde de surface, placer cette dernière perpendiculairement à la surface de l'objet.
Noter que l'application d'huile sur la sonde afin d'assurer un meilleur contact peut améliorer la précision de la mesure.
- Lors de la mesure de la température sur une surface non-métallique, s'assurer que la durée de la mesure est suffisante pour compenser la mauvaise conductivité thermique.
- Pour assurer une mesure stable, l'instrument ne doit pas subir de changement de température brutal.
- Cet instrument, à l'exception de la partie connecteur, est résistant à l'eau, mais pas étanche à l'eau. C'est pourquoi l'instrument ne doit pas être immergé dans l'eau. S'il se retrouve par erreur immergé dans l'eau, le retirer immédiatement et s'assurer que l'eau n'a pas pénétré à l'intérieur du boîtier. Même si l'instrument est conçu pour que toute quantité d'eau pénétrant dans le connecteur n'entre pas dans le circuit du boîtier, il faut essayer d'éviter que de l'eau entre dans le connecteur.
Si de l'eau entre dans le connecteur, l'écran endommagé risque d'être indisponible.

4. Specifications

Thermocouple type:	K, J, E, T
Measuring range:	Type K: -200°C to 1372°C Type J: -200°C to 1000°C Type E: -200°C to 700°C Type T: -200°C to 400°C
Measurement resolution:	-200.0°C to 199.9°C: 0.1°C 200°C or higher: 1°C
Accuracy (instrument):	[At ambient temperature of 23 ± 5°C] -200.0°C to -100.1°C: 0.1% of rdg + 1.0°C -100.0°C to 199.9°C: 0.1% of rdg + 0.7°C 200°C or higher: 0.2% of rdg + 1°C Reference junction compensation accuracy (±0.4°C) included When the input terminal temperature is balanced
Temperature coefficient:	[In the ranges from 0 to 18°C and 28 to 50°C] ±(0.015% of rdg +0.06°C)/°C
Measurement cycle:	Approx. 1 second
Operating temperature/humidity:	0°C to 50°C, 20 to 80% RH (no condensation)
Storage temperature/humidity:	-10°C to 60°C, 5 to 95% RH (no condensation)
Power requirements:	Two AA alkaline dry batteries (LR6)
Battery life:	Approx. 450 hours
Display:	Reflective LCD; 7-segment, 4-digit display and 30 character segments Difference between 2 channels (2ch model only)
Battery alarm:	Displayed on LCD ()
Key operation sound:	Internal buzzer sounds during key operation
Auto power-off:	Turns off the power 10 minutes after the last key operation (can be disabled)
Degree of protection provided by enclosures:	Equivalent to IP54 (when using the waterproof cover ^{*3})
Dimensions:	Approx. 151 (H) × 56 (W) × 33 (D) mm (excluding protrusions)
Weight:	Approx. 180 g (including batteries)
Accessories:	User's manual, Two AA alkaline dry batteries (LR6)

Safety standards:	EN 61010-1, EN IEC 61010-2-030 Measurement category O (Other) Indoor use, altitude 2000 m or less, pollution degree 2
EMC standards:	EN 61326-1 Class B Table 1, EN 55011 Class B Group 1 Group 1: Equipment that does not intentionally generate or use radio-frequency (RF) energy EMC Regulatory Arrangement in Australia and New Zealand Korea Electromagnetic Conformity Standard (한국 전자파적합성기준) The accuracy rating of all ranges are the sum of the accuracy levels in standard applications and the accuracy tolerances shown below, where the overall length of cable, including the probe, is assumed to be shorter than 3 m. Accuracy tolerance of all available ranges: ±5% of span
Environmental standards:	EU RoHS Directive compliant For conformity to environmental regulations and/or standards other than EU, contact your nearest YOKOGAWA office (PIM113-01Z2).

5. Accessories (Optional)

TC-K Probe (Temperature probes for thermocouple type K)				
Model	Probe type	Measuring range	Sensor Diameter/ Length (mm)	Tolerance
90020B	Rounded end	-50 to 600°C	φ 3.2/200	T < 375°C: ± 1.5°C
90021B	Rounded end	-50 to 600°C	φ 1.6/150	375°C ≤ T: ± 0.004 × T°C
90022B	Rounded end	-50 to 600°C	φ 3.2/500	
90023B	Needle	-50 to 500°C	φ 1.6/100	
90024B	Needle	-50 to 500°C	φ 2.1/100	
90030B	Surface straight	-20 to 250°C	φ 15 ^{*1}	(T-Ts) ≤ 100°C: ± 2.5°C 100°C < (T-Ts): -0.03 × T to +2.5°C T: -20°C to 250°C, Ts: 0°C to 40°C
90031B	Surface angled	-20 to 250°C	φ 15 ^{*1}	
90032B	Surface straight	-20 to 500°C	φ 15 ^{*1}	(T-Ts) < 333°C: +2.5°C 333°C ≤ (T-Ts): +0.0075 × T°C (T-Ts) < 167°C: -2.5°C 167°C ≤ (T-Ts): -0.015 × T°C T: -20°C to 500°C, Ts: 0°C to 40°C
90029B	Bead TC	-40 to 260°C	1200 mm ^{*2}	± 2.5°C
T: measurement temperature, Ts: ambient temperature				
245921	Extension cable (5 m)			
245922	Extension cable (10 m)			
93012	Carrying case			
93011	Waterproof cover ^{*3} (5 pcs)			
[Note]				
^{*1} : Diameter of thermosensitive part 15 mm dia.				
^{*2} : Length of probe (included cord)				
^{*3} : The 93011 has been discontinued.				

6. Regulations and Sales in Various Countries and Regions

6.1 Waste Electrical and Electronic Equipment (WEEE)


(EU WEEE Directive valid only in the EEA* and UK WEEE Regulation in the UK)

This product complies with the WEEE marking requirement.

This marking indicates that you must not discard this electrical/electronic product in domestic household waste.

When disposing of products in the EEA or UK, contact your local Yokogawa office in the EEA or UK respectively.

(*EEA: European Economic Area)



6.2 Batteries and Waste Batteries

(EU Battery Directive/Regulation valid only in the EEA and UK Battery Regulation in the UK)

Batteries are included in this product.

When you remove batteries from this product and dispose them, discard them in accordance with domestic law concerning disposal.

Take a right action on waste batteries, because the collection systems in the EEA and UK on waste batteries are regulated.



Battery type: Alkaline dry cell

This marking indicates they shall be sorted out and collected as ordained in the EU battery Directive/Regulation and UK battery Regulation.

How to remove batteries safely:
For further details, see chapter 9, “Battery Replacement” in the User’s Manual (IM TX10-01-02EN).

6.3 Authorized Representative in the EEA

Yokogawa Europe B.V. is the authorized representative of Yokogawa Test & Measurement Corporation for this product in the EEA.
To contact Yokogawa Europe B.V., see the separate list of worldwide contacts, PIM 113-01Z2.

6.4 Disposal

When disposing of this instrument, follow the laws and ordinances of the country or region where the product will be disposed of.
If you are disposing of the product in the EEA or UK, see also section 6.1, “Waste Electrical and Electronic Equipment (WEEE).”

■ Notice Regarding This Manual

- The contents of this manual are subject to change without prior notice as a result of improvements to the product’s performance and functionality.
Refer to our website to view our latest manuals.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without the permission of YOKOGAWA is strictly prohibited.